


[To update your dongle]


① Double click SST G1 Pro to launch.

*Do not open a project or image file.

② Go to the Help menu, and select “Dongle Settings.”



③ Click “Obtain Locking Code.”




④ The following message will appear: Would you like to create locking code file?


Click “Yes.”



⑤Enter a four digit alphanumeric Dongle No. as a file name, and select where to save the file.



⑥Ensure that the Locking Code that was automatically provided in step 4 appears in the box, and then click “Close.”




⑦A .loc file will be created in the save location you selected. Send an e-mail with the file attached to CANVASS Co, Ltd. at sales@canvass.co.jp *Make sure to include your name in the email.




⑧An email with a .lic file attached will be sent to you from CANVASS Co, Ltd., so save this file to your PC.



⑨Open the “Dongle Setting” dialog box as in step No.②, and click “Read File.”




⑩Select the .lic file, and click “Open.”



⑪License code

Make sure that the License Code that was automatically provided in step 9 appears in the box, and then click “Overwrite Dongle.”



⑫The following message will appear.



Once this process is complete, the new functions will become available. Also, when SST G1 Pro is launched, the license expiration warning will no longer appear.